

Contact Us

www.gettaof.com

gettaof@gmail.com

PROTAGONIST USER GUIDE

T A O F

T A O F



Her 「PROTAGONIST」

“ You Are The Protagonist Of Your Own Story ”

[Package Contents


01]



Protagonist



Dust Cap




Lubricants



Charging Cable




User Manual



Storage Pouch

Get to Know Your Protagonist



Button Guide

Decrease Button
Press and hold for stepless speed reduction; short press to cycle down to lower intensity levels.




Power Button
Press and hold for 2 seconds to power on. Short press during operation for instant pause. Double-click to cycle through suction pattern modes.

Increase Button
Press and hold for stepless speed increase; short press to cycle up to higher intensity levels.

[Functions & Operating Instructions


Lubricant Cartridge Installation, Dispensing & Priming

Step 1




Pry open the bottom cover of the main unit

Step 2




Unscrew the lubricant pump head

Step 3




Insert the lubricant cartridge vertically into place

Step 4




Secure the bottom cover back onto the main unit

Step 5



Press and hold the O-shaped button until the purple indicator lights up to power on the device.

Step 6




First short-press the droplet button. Wait 5–10 seconds after the activation sound, then press and hold for 5–10 seconds until lubricant is dispensed from the suction opening.

Important Notes


The brand-new Protagonist comes with approximately 80% battery charge out of the box. The suction function is ready for immediate use with no activation required. The lubricant dispensing function must be activated first.

(For activation steps, please refer to the *Lubricant Cartridge Installation, Dispensing & Priming* section on Page 3.)


Versatile Suction Modes



Press the droplet-shaped button until lubricant is dispensed.



Double-click the O-shaped button to switch modes.
5 variable pattern modes are available in total.




Short-press the + or – button to cycle between lower and higher intensity levels.
Press and hold the + or – button for stepless speed adjustment, for smooth and seamless intensity changes.



Short-press the O button for instant pause.

Travel Lock


If you plan to travel with the Protagonist, press and hold the **+** and **=** buttons simultaneously for 3 seconds. The travel lock is activated when the button indicator flashes, preventing accidental activation during transport. To deactivate the travel lock, repeat the same steps. The Protagonist is approved for carry-on luggage and can pass through standard airport security screening.



[Directions for Use

1. Understanding Your Anatomy

The Protagonist is an external suction device designed specifically for clitoral (C-spot) stimulation.





Introduction to the Clitoral C-Spot

2. Operating Instructions

You may rinse the Protagonist with clean water before use. The device body has an IPX7 waterproof rating.

Install the lubricant cartridge (for detailed installation steps, please refer to the *Functions & Operating Instructions* section).

Find a comfortable position: lying on your back, side-lying, sitting, or held by a partner.




Apply a suitable amount of lubricant and activate the suction function. Gently place it against the clitoris, adjust the position and angle to build arousal.


Switch between modes and adjust intensity levels to enjoy a range of continuous, varied sensations.

3. After Use

Clean the device after use and store it in a dry place. To replace the lubricant cartridge, pry open the bottom cover and remove the empty cartridge. Unscrew the pump head from the new lubricant cartridge, then insert the new cartridge into the device.




IPX7 waterproof rating for the full device body
Rinse with clean water before and after use
Store dry



When replacing the lubricant cartridge, remove the empty cartridge first. Unscrew the pump head from the new cartridge, then insert the cartridge into the device.

This device uses magnetic charging. When the pin-contact charging cable is connected to the bottom of the Protagonist, the indicator lights on the Nüshu-shaped buttons will pulse slowly. The indicators stay solid once the device is fully charged.



Button indicators pulse slowly: Charging in progress

Button indicators stay solid: Charging complete

A full charge takes approximately 60 minutes.

When fully charged, the Protagonist delivers approximately 90 minutes of continuous use.

1. The main unit is constructed from food-grade silicone with an IPX7 waterproof rating. You may safely rinse it with water after use. Soaking the device or cleaning it with alcohol-based products is not recommended, as this may shorten its service life.
2. After cleaning, wipe the device dry and place it on a dry surface, or store it in the included dust-proof storage pouch.
3. Charge the device once per month to maintain proper cycle performance of the lithium battery.
4. Avoid prolonged exposure to direct sunlight. Do not store the device in high-temperature environments.

Product Name: ProtagonistMaterial: Food-grade silicone + ABS

Number of motors: 2PCS

Product dimensions: Main unit 227 × 34.5 × 99.5 mm

Suction Opening Diameter: 19 mm

Product Weight: 175.1 g (main unit), 38.4 g (dust cap with pearl chain)

Battery Capacity: 280 mAh

Rated Voltage: 3.7 V

Rated Power: 3 W

Rated Current: 400 mA

Charging Time: < 60 min

Operating Time: > 40 min

Waterproof Rating: IPX7

Q1: Can the Protagonist be rinsed directly with clean water before and after use?

A1: Yes. The main unit of the Protagonist carries an IPX7 waterproof rating, so you may safely rinse it with water after use. However, soaking the device or cleaning it with alcohol-based products is not recommended, as this may shorten its service life.

Q2: Why don't I feel any sensation from the suction function?

A2: Everyone's body responds differently and has varying levels of sensitivity. This is completely normal, especially for first-time users, and it may take some trial and exploration. External clitoral stimulation remains the most beginner-friendly form of stimulation. We recommend following the manual to locate the clitoris (C-spot), try different intensity levels and frequencies on the Protagonist, and take your time to find the rhythm and sensation that suits you best.

Q3: Why is there a lubricant function for external suction use?

A3: Many people assume lubricant is unnecessary for non-insertable use. In fact, especially for new users, applying lubricant minimizes friction irritation to the clitoris and greatly improves the comfort of the suction experience. Dispensing an appropriate amount of lubricant by long-pressing the droplet button before each use is a simple tip for a more comfortable experience.

Q4: Is the built-in lubricant hygienic? Can bacteria from the skin or the environment contaminate the lubricant inside the Protagonist?

A4: The Protagonist uses a sterile vacuum peristaltic pump system that prevents lubricant backflow — the lubricant only flows outward in one direction. There is no risk of backflow contamination during or after use. This specialized structural design allows the Protagonist to safely store lubricant long-term after simple cleaning.

Her future, for you.

Warranty Terms

1. For the health and safety of all customers, intimate products are not eligible for trial use.
2. The 7-day hassle-free return and exchange policy is valid only when the product's outer packaging shrink wrap remains intact and unopened.
3. TAOF products are covered by a 1-year warranty from the date of purchase. This warranty applies to all quality issues caused by manufacturing or material defects.
4. This warranty covers damage resulting from inherent product quality issues. It does ****not**** cover cosmetic wear from normal long-term use, nor damage caused by improper operation, negligence or accidental circumstances.
5. Do not attempt to disassemble the product on your own. Unauthorized disassembly will void the free warranty service.
6. If you encounter any quality issues within the warranty period, please contact gettaof@gmail.com or gettaof.com or other official channels. We will provide a free product replacement and cover all return shipping costs.
7. Valid proof of purchase is required for all warranty claims to confirm the product is still within the warranty period. Please keep your purchase receipt in a safe place. Thank you for your understanding and support.